

MEDINTECH PLUS

Homogeneous Vinyl Sheet

For Commercial Applications



INSTALLATION

• Job Condition

Subfloor / underlayment shall be hard, levelled, dry, clean and smooth. They shall be free from paint, varnish, solvents, wax, oil, existing adhesive residue or any other foreign matter. Acclimatize all flooring materials and adhesives to room temperature at least for 72 hours prior to installation.

Note : Cementitious self levelling compound should be used to achieve zero level sub-floor.

• Procedure

Installation shall be carried out according to Armstrong's recommendations (www.armstrong.co.in). The recommended adhesive should be used to ensure satisfactory installation.

• Adhesive

Armstrong recommends VOC free water based adhesive like Arbond 44 of Arofine Polymer or equivalent. Rubber based adhesives or any other solvent based adhesives should not be used with Medintech Plus. Rubber based adhesives should be limited for accessories installation only.

MAINTENANCE

- Dry mop with microfiber cloth thoroughly
- Damp mop with a dilute neutral detergent solution
- Black marks and dirty spots can be treated by spot scrubbing (use nothing more abrasive than a 3M blue or green pad or equal)
- Use Armstrong "Cleaner", "Protect", "Shinekeeper" and "Stripper" for maintenance. Refer Armstrong maintenance brochure for details

WARRANTY

Armstrong warrants its product to be free from manufacturing defects for five (5) years from the date of purchase. For detail warranty please contact Armstrong sales representative.

Armstrong World Industries (India) Pvt. Ltd.

Boomerang, A-304, Chandivali Farm Road (near Chandivali Studio) Andheri (E), Mumbai - 400 072
Tel: 022-3048 0800, Fax: 022-3046 0439 / 2491 3604 | e-mail : helpdeskindia@armstrong.com

Branches:

Ahmedabad : +91-85111 46309	Bengaluru : +91-80-2657 6367	Chandigarh : +91-172-2633 680
Chennai : +91-44-4217 5303	Gurgaon : +91-93126 73142	Hyderabad : +91-40-3200 9868
Pune : +91-20-3250 2404	Kolkata : +91-33-2401 4755	Lucknow : +91-522-220 1143

Representatives:

Bhopal : +91-93237 99834	Bhubaneswar : +91-99039 20499	Cochin : +91-99477 87111
Coimbatore : +91-93677 81490	Dehradun : +91-93169 19120	Goa : +91-93255 02140
Guwahati : +91-99030 81018	Indore : +91-93237 99834	Jaipur : +91-93525 69512
Jammu : +91-93169 19120	Ludhiana : +91-93169 19120	Nagpur : +91-93237 99834
Nashik : +91-93255 02140	Patna : +91-93126 73148	Raipur : +91-93255 02140
Ranchi : +91-99039 20499	Surat : +91-85111 46309	Trivandrum : +91-99477 87111
Vizag : +91-93938 96055		